

LAMINATE FLOORING

Maintenance & Care Guidelines

Effective August 10, 2026

Maintenance

- Never use wax, polish, oils, soaps, detergents, shine or varnish on the floor.
- For dry maintenance, we recommend a dust mop or vacuum cleaner with soft bristle brush only.
- For slightly damp maintenance, we recommend a laminate cleaner which you spray directly and lightly on a duster. Always wipe dry immediately until no more moisture is visible on the floor. For bevel edge products, we strongly recommend dry cleaning only.
- Do not use any type of cleaning machine such as spray mops, steam cleaners/mops or power cleaners.
- Wet maintenance is absolutely forbidden. Remove any water immediately. Our laminates are not suitable for use in damp spaces like saunas.
- Remove stubborn stains carefully with acetone based fingernail polish remover. Never use scouring products!
- In case your floor needs repair, the planks can easily be removed in minutes without replacing the entire floor. The required expansion gap must be in place around the room's perimeter and extra flooring should be available for use in the repair.

Enjoy your floor!